

Совместим со следующими моделями:

H147I/HC	WW12K8412OW/SC	WW12K8412OW/EF
H147W/HC	WW12K8412OW/SE	WW12K8412OW/E O
WW11K8412OW/GU	WW12K8412OW/SG	WW12K8412OW/E P
WW11K8412OW/SA	WW12K8412OW/ST	WW12K8412OW/E U
WW12K8402OW/EE	WW12K8412OW1F Q	WW12K8412OW/F Q
WW12K8402OW/EG	WW12K8412OX/EU	WW12K8412OW/LE
WW12K8402OW/EN	WW12K8412OX/FA	WW12K8412OW/LP
WW12K8402OW/ET	WW12K8412OX/FH	WW12K8412OW/LV
WW12K8402OW/WS	WW12K8412OX/LP	WW12K8412OX/TC
WW12K8412OW/AH	WW12K8412OX/MF	WW1BK8402OW/W S
WW12K8412OW/EC	WW12K8412OX/SV	